

Instruction manual for parcel box deliverers



Instruction manual parcel box deliverer



Table of Contents Page

Device Overview	2
Parcel delivery	3
Pick-up parcel (pick@home)	4

Device overview

The TPAS information terminal is a touch panel control unit and serves as a display at Control unit for the parcel box functions within a parcel box and letterbox system of Ernst Schweizer AG.

Device overview information terminal (touch panel display)

Front

- 1. Search field
- 2. Bell function (if available)
- 3. Names of the residents
- 4. Parcel symbol (for delivery of parcels)



Instruction manual parcel box deliverer



Parcel delivery

Press the recipient's parcel button (Search name using the search field (magnifying glass) or search the list of names by scrolling)


The parcel locker menu will open

Select the desired parcel locker size

(• Cancel with)

The desired parcel locker will open

The package can be deposited






Information

Parcel box position indicator

On free-standing letterbox systems equipped with parcel boxes on both sides, the parcel delivery person is shown whether a parcel compartment is located at the back when selecting it.



Instruction manual parcel box deliverer



Pick-up parcel (pick@home)


Press on the package icon of the desired resident

(Search name using the search field (magnifying glass) or search the list of names by scrolling)

Information


Icon with yellow rhombus = ready for pick@home





Press the pick@home icon





(• Cancel with)

Entering the last 4 digits of the pick@home shipping label

The desired parcel locker will open

Information

In case of multiple incorrect input (e.g. by repeatedly pressing the Enter key), the input locks for about 2 minutes





Information

Parcel box position indicator

On free-standing letterbox systems equipped with parcel boxes on both sides, the parcel delivery person is shown whether a parcel compartment is located at the back when selecting it.

